



Home Lift

Lifton**DUO**
User Manual



Introduction	03
<hr/>	
Important Information Prior to Initial Operation	04
<hr/>	
Description	05
Lift Components	05
LED Display Lights, Control Panel Inside the Lift Car, Remote Control	06
<hr/>	
Safety Features	07
Safety Sensors in the Lift Car Roof and Lift Car Floor	07
Locking Mechanism, Light Curtain	07
Additional Safety Sensors	08
Emergency Features	08
Safety Brake, Motor and Gear Brake	09
Emergency Power Supply	09
<hr/>	
Lift Operation	10
Using the Lift Car	10
Calling the Lift	10
<hr/>	
Troubleshooting	11
<hr/>	
Supplementary Information	12
<hr/>	
Declaration of Conformity	13



Introduction

Thank you for purchasing the Lifton Home Lift. We are confident that this lift will make your life easier, safer and more comfortable. The Lifton Home Lift is a Domestic Personal Home Lift that complies with Machinery Directive 2006/42/EG. To ensure continued satisfaction with your Lifton Home Lift, please ensure you always follow these instructions:

- Please read this user manual carefully before using your Lifton Home Lift. This will help ensure safe, easy and correct operation of the lift.
- In the event of malfunction, please refer to the chapter “Troubleshooting” first. Potential failure may be caused by the safety devices of your Home Lift. It is very likely that you can correct these issues quickly and easily yourself. We are happy to provide phone support if needed. To get in touch with us, please call our freephone customer service number on 0330 222 0334.
- Even a solidly-built and technically low-maintenance lift such as the Lifton Home Lift should be maintained on a regular basis; once a year is ideal. This maintenance ensures continued safety, and increases the long-term reliability of the lift.
- Maintenance of your lift is even easier if you sign up for a regular warranty agreement to extend the life of your LiftonDUO. This is optional, however we do recommend it in order to keep your lift in optimal condition.
- We strongly recommend that you have all service and maintenance work to your Lifton Home Lift, carried out by an authorized Lifton service technician.
- You should never use the lift in the event of a fire.

We hope that you'll enjoy your new Lifton Home Lift.

Important Information Prior to Operation

The Lifton Home Lift has been equipped with a number of safety and emergency features to ensure safe usage at all times. Nevertheless, it is essential that the lift is operated in accordance with the user manual to ensure that no accidents occur.

1. The lift is motorised with moving parts. Only those who have been shown how to operate it and who understand that they are responsible for starting, travelling in and stopping the lift safely - and have been cautioned on the potential hazards - should operate it.

2. The lift is not a toy. Children under 14 years old should not be permitted to play with or inside the lift. Children should only operate the lift if under adult supervision and only use it for its intended purpose.

3. Much like a stair case, this lift can pose a particular risk to small children when on the upper floor, without adult supervision. In particular, when the lift is called from the lower floor while a small child is on the upper floor, the child could potentially crawl into the partially lowered lift (if the lift has the half door option fitted). The safety light barriers stop the lift ride as soon as there is an obstruction detected in the entrance area. However, that system does not protect a child from potentially falling into the partially lowered lift. It is the user's responsibility to ensure that such a situation does not occur.

As an additional precautionary measure, a protective grille is available and can be installed to screen the opening. This would ensure a small child cannot get into the lift while it is being called. The grille is not part of the standard equipment since it could pose difficulties for people with limited mobility, for whom this lift is designed. As an alternative, the lift could be locked when small children are in the vicinity.

Description

Lift Components

1	Cover Panel for electrics and hoist unit
2	LED Lights
3	Control Panel
4	Guide Rails
5	Seat (not shown)
6	Lift Car Floor with safety sensors
7	Locking Mechanism
8	Door
9	Safety Handle (not shown)
10	Lift Car Roof with safety sensors
11	Floor Cover




Description


LED display lights on control panel



Control Panel inside the Lift Car



Remote Control



Safety Features

The numerous safety features have been designed to ensure safe and comfortable lift travel at all times. They prevent - or stop - the lift from moving in case of a malfunction or in the event of an object or person blocking the operating radius.

In order to guarantee this and to protect the lift against potential failure, all safety features must be activated before operating the lift.

It is important that you are familiar with all safety features.

Safety Sensors in Lift Car Roof and Car Floor

There are safety sensors in the Lift Car floor and Lift Car roof which will stop the lift immediately if it comes into contact with any obstacle. The lift can then only proceed in the opposite direction. The journey can be continued as soon as the obstruction has been cleared.



Locking Mechanism and Light Curtain

The door's locking mechanism ensures that the Lift Car door stays closed while the lift is moving. Sensors check - even before moving - whether the door has been closed. A key for the lift door is provided to open the safety catch and let passengers exit in an emergency situation.

All lifts are equipped with a full-height light curtain. This safety light curtain creates a barrier across the entrance of the lift and either prevents, or stops, the lift from moving further if there is an obstruction blocking the safety light curtain. To notify the user that the safety light curtain is obstructed, a red warning light will be flashing on the control panel inside the cabin.





Additional Safety Sensors

Balance sensors will warn the Lift Car user if a problem exists with either of the lift cables.

Overload sensors will determine whether the lift is overloaded prior to moving. To notify the user that the lift is overloaded, the related area on the control panel inside the cabin will flash. (See page 6).

The Slack Rope sensor detects if the lift ropes are

slack and will prevent the lift car from attempting to travel any further.

In the unlikely event that the regular limit switches should fail, there are auxiliary switches located above and beneath the Lift Car. If those should fail at the same time, there are further back up switches that will stop the lift in an emergency. Once those emergency stops are activated, the lift will stop until the incident has been investigated by a service technician, and the problem has been corrected.

Emergency Features

The lift is equipped with an emergency stop button. Pressing the red emergency stop button while travelling in the lift will stop the lift immediately and trigger the alarm. Therefore, this button should only be used in extreme situations; such as the lift failing to stop when the control button is released. The emergency system must be reset once the cause of the incident has been resolved.

A key switch prevents operation while the lift is in "off" mode. This switch can also reset the controls after an emergency stop.

There is a phone handset located underneath the control panel inside the cabin, which will enable immediate contact in case of emergency.

Safety Brake, Motor and Gear Brake

In the event of any motor or gearbox issues, an integrated brake system will stop the lift. The safety brake stops the lift immediately in the unlikely event of a hoist rope failure. If any of these safety features are activated, they must be disengaged and reset by a Lifton Home Lift service technician.



Emergency Power Supply

In the event of a power failure occurring whilst the lift is in operation, the emergency power supply and emergency lights will activate automatically. The lift can be moved down to the lower floor on emergency power by using the normal lift controls. If this happens, the button which moves the lift to the upper floor will be disabled. All safety features remain fully operational while lowering the lift on emergency power.

In order to ensure that the emergency power supply is charged at all times, the lift's power plug should never be disconnected from the mains.

Lift Operation

Travelling in the Lift

1. When entering the lift, the lights come on automatically. Stand (or sit) in the lift facing the opening.
2. Close the door and make sure that you are not obstructing the safety light curtain across the lift entrance. If obstructed, the lift will not travel and a buzzing sound will indicate continued obstruction of the safety light curtain. If you are in the entrance area, there will also be a red light flashing indicating an light curtain obstruction.
3. If the load is greater than specified for this lift (170kg) the overload light will be flashing. The lift will not move until the weight is reduced.
4. Ensure any passengers or items travelling with you are fully contained within the lift car.
5. Select the desired direction (see image of control panel on page 6). Depress and hold the appropriate button for travelling up or down. The lift will move while the button is depressed.
6. Hold the button down until the lift stops at its destination.
7. If you see an unsafe situation, release the button and either wait until it is safe to continue or return to the floor from which you came.

Calling the Lift

You can position the two remote controls anywhere around your home and these allow you to control the lift, and to call it when it's parked on the other level. The remote control can be used to move the lift to the desired floor.

1. If possible, first check to make sure that nobody is inside the lift trying to operate it from within.
2. Press the call button on the remote control and keep it pressed until the lift has come to a stop on the desired floor. Please note: you can stop the lift at any time by releasing the button.
3. If the lift encounters an obstruction when being called either up or down, it will stop. If this occurs, reverse the direction the lift is travelling in and return it to the starting point. Clear the obstruction, and as soon as the obstacle has been removed from the operation area, the lift will continue its journey.

Troubleshooting

Problem	Possible cause	Solution
The lift will not operate	The light barrier protecting the cabin entrance is obstructed. The barrier light is flashing and a buzzing sound can be heard	Remove the obstruction
	The key switch is off	Turn it back on with the key
	The emergency stop button has been pressed	Reset it; turn the key switch 'off' and then back 'on'
	The power is off. The red display light is off.	Wait until the main power is restored OR switch it back on at the fuse switch
	Someone has tried to manually move the lift car	Contact a service technician. The lifting mechanism may be displaced
	The door is not completely closed	Close the door
Both light curtain and overload lights are flickering and flashing alternatively	The over-speed sensor has failed	Contact a service technician
The remote controls won't operate the lift	Remote control batteries may need replacing	Replace the batteries
The lift car will not travel downwards, but will only travel upwards	There is an obstruction under the lift car	Remove the obstruction
The lift car will not travel upwards, but will only travel downwards	The main power is off and the lift car is operating on the emergency battery	Wait until the main power is restored
	There is an obstruction on the safety cover	Remove the obstruction
	The safety cover could be catching on the guides etc., as it is being lifted	Safely observe from the upper floor whether the cover is tilting instead of coming up level

If the lift remains inoperable after following all instructions, use the key switch to turn the lift off and then back on. The control unit will then perform a check of all the electrical circuits and reset them if necessary. This is usually all that is required to reset the lift and restore normal operation. **If the lift still will not operate normally after resetting it with the key, please contact a service technician.**

Supplementary Information

Intended use	The Lifton is authorised for the exclusive purpose of transporting the intended individuals only
Installation/Repair/Disassembly	All installation/disassembly and service work must be carried out by an authorized Lifton service technician
Caution	<ul style="list-style-type: none">• For safety reasons, the removal or modification of any parts or components of the Lifton Home Lift is prohibited• Do not use the Lifton Home Lift in the event of fire
Environment	<ul style="list-style-type: none">• The ambient operational temperature should not fall below 5 °C• Do not operate your Lifton Home Lift in a potentially explosive environment• The Lifton Home Lift is designed for indoor use only
Emergency Telephone	<ul style="list-style-type: none">• In case of an emergency, please always call the freephone Lifton Home Lift number for assistance first• The number is 0330 222 0334

WARNING To ensure that the emergency power within the lift is charged at all times, the power plug of the Lifton Home Lift should never be disconnected from the mains supply.

Declaration of Conformity



Stiltz Limited
Building 5, Bay 1
First Avenue
Pensnett Estate
Kingswinford
West Midlands, DY6 7TE, UK

Service: 0330 222 0334
Sales: 0800 471 4719
Email: info@stiltz.co.uk

www.stiltz.co.uk

Date: 1st April 2016

EC DECLARATION OF CONFORMITY FOR MACHINERY

Manufacturer:

Stiltz Limited
Building 5, Bay 1
Pensnett Estate
Kingswinford
West Midlands
DYS 6TE, United Kingdom



Herewith declares that the 'Lifton' Duo lift is in conformity with the provision of the;

Machinery Directive 2006/42/EC
The Low Voltage Directive 2006/95/EC
The Electromagnetic Compatibility Directive 2004/108/EEC

The unique serial number of your lift is: _____

Dated: 01 / 4 / 2016

Cameron Gillespie
EU Representative of Manufacturer

(Print) _____

Dated: _____

Local Installer

”

We hope that you enjoy
your new Lifton Home Lift







Lifton UK

Building 5, Bay 1
First Avenue
Pensnett Estate
Kingswinford
DY6 7TE

0330 222 0334

lifton.co.uk